



## Series AE-Sub-base “MIXED” Valves

### Valve Part Number

AE-1009	ISO 1 5/2 valve-pilot/spring
AE-1120	ISO 2 5/2 valve-pilot/spring
AE-1010	ISO 1 5/2 valve-pilot/pilot
AE-1121	ISO 2 5/2 valve-pilot/pilot

The sub-base is not included

### Valve Part Number

AE-1000	ISO 1 5/2 valve-solenoid/spring
AE-1001	ISO 1 5/2 valve-solenoid/spring
AE-1100	ISO 2 5/2 valve-solenoid/spring
AE-1101	ISO 2 5/2 valve-solenoid/spring

The sub-base is not included

All solenoid valves are supplied less coil & connector. See bottom of page for coil & connector information.

### Valve Part Number


AE-1003	ISO 1 5/2 valve-solenoid/solenoid
AE-1004	ISO 1 5/2 valve-solenoid/solenoid
AE-1103	ISO 2 5/2 valve-solenoid/solenoid
AE-1104	ISO 2 5/2 valve solenoid/solenoid

The sub-base is not included

All solenoid valves are supplied less coils & connectors. See below for coil & connector information.



AE-1009 AE-1010  
AE-1120 AE-1121



AE-1000 AE-1001



AE-1003 AE-1103

## Coils & connectors

Valve Part Number	Solenoid Coil Part Number					Connector Pt.No.
	12vDC	24vDC	24vAC	110vAC	220vAC	
AE-1000	DA-0050	DA-0051	DA-0106	DA-0108	DA-0124	AM-5110
AE-1001	DA-0050	DA-0051	DA-0106	DA-0108	DA-0124	AM-5110
AE-1100	DB-0501	DB-0502	DB-0507	DB-0509	DB-0510	AM-5111
AE-1101	DB-0501	DB-0502	DB-0507	DB-0509	DB-0510	AM-5111
AE-1003	DA-0050	DA-0051	DA-0106	DA-0108	DA-0124	AM-5110
AE-1103	DB-0501	DB-0502	DB-0507	DB-0509	DB-0510	AM-5111
AE-1004	DA-0050	DA-0051	DA-0106	DA-0108	DA-0124	AM-5110
AE-1104	DG-0501	DB-0502	DB0507	DB-0509	DB-0510	AM-5111

## Repair Kits

Kit Part Number	Valve Part Number
AE-1047	AE-1000,AE-1001 & AE-1009
AE-1048	AE-1010,AE-1003 & AE-1004
AE-1142	AE-1100,AE-1101 & AE-1120
AE-1143	AE-1103,AE-1104 & AE 1142

These valves are just a part of the AE Series please call for information on other models